

IRON BALTIC

ALUMINIUM SKID PLATE

CFORCE

625 Touring (...-2022)

Code 02.25700

Version 06102023



Keep this manual for future reference!

If you need any spare parts, please send this packaging data to your local dealer or to Iron Baltic sales@ironbaltic.com

Iron Baltic Ltd | +372 653 3711 | sales@ironbaltic.com | www.ironbaltic.com



DOWNLOAD MULTILINGUAL
USER MANUAL



code.ironbaltic.com/u/mcvCQRzK


SPECIFICATION

Pos.	Description	Code	Amount
1	Front protection	02.25701K	1
2	Middle protection	02.25702K	1
3	Rear protection	02.25703K	1
4	Right sideprotection	02.25704	1
5	Left sideprotection	02.25705	1
6	Front right arm protection	02.27104	1
7	Front left arm protection	02.27105	1
8	Rear right arm protection	02.1076P+	1
9	Rear left arm protection	02.1076V+	1
10	Installation plate	02.718	3
11	Connecting plate	02.5006	9
12	Installation bracket	02.5709	5
13	Oil hole plate	02.15006K	1
14	Bracket	03.1502	2
15	Distance plate	05.3902	2
16	Conical washer 8	14.501	2
17	Conical washer 6	14.502	6
18	Dished washer	14.503	41
19	Bolt M6x14 DIN933	OT.02.02.040	27
20	Bolt M6x20 DIN933	OT.02.02.060	7
21	Bolt M6x20 DIN7991	OT.02.04.030	6
22	Bolt M6x30 DIN933	OT.02.02.080	4
23	Bolt M6x35 DIN933	OT.02.02.090	6
24	Bolt M8x20 DIN7991	OT.02.04.150	2
25-1	Bolt M8x45 DIN933	OT.02.02.230	2
25-2	Bolt M10x1,25-45 DIN961	OT.02.08.349	2
26	Washer Ø6/15 SFS3738	OT.04.03.020	52
27-1	Washer Ø8/20 SFS3738	OT.04.03.030	2
27-2	Washer Ø10 DIN125	OT.04.01.040	2
28	Nyloc nut M6 DIN985	OT.03.02.030	8




FITTING INSTRUCTIONS

Step 1 Remove standard skid plate, plastic mud deflectors and winch fairlead.




Step 2 Install installation plates 02.718 (Pos. 10) and brackets 02.5709 (Pos.12) to the ATV frame.



Step 3

Install oil hole plate 02.15006K (Pos. 13) and original mud deflectors, removed at Step 1, to the middle part




Step 4

Install middle protection 02.25702K (Pos. 2).
Use original plastic clips to fasten mud deflectors




Step 5

Install connecting plates 02.5006 (Pos. 11) to middle part.





Step 6

Install skid plate front part 02.25701 (Pos. 1). Install distance plates 05.3902 (2 pcs) between the skid plate front part and original winch fairlead holder. Use M8 or M10 bolts/washers, according to your ATV, to secure the winch fairlead.




Step 7

Install skid plate rear part 02.25703K (Pos.3).




Step 8

Install sideprotections 02.25704 (Pos.4) and 02.25705 (Pos.5).





Step 9

Install front A-arms protections 02.27104 (Pos.6) and 02.27105 (Pos.7).





Step 10

Install rear A-arms protections 02.1076P+ (Pos.8) and 02.1076V+ (Pos.9). First install the bracket 03.1502 (Pos.14) to the arm protection (do not tighten the bolt). Then place the protection on to the ATV's A-arm. Press the guard against the A-arm tube and tighten the bracket bolt so that the side of the bracket is against the A-arm tube. Finally, attach the other side of the A-arm protection.



Step 11

To remove the oil cover plate, remove two bolts indicated with arrows and loosen the third bolt. Slide the plate away.



IRON BALTIC

IRON BALTIC OÜ
Joa tee 17
Vääna 76903
Estonia / Europe

+372 6 533 711
sales@ironbaltic.com

www.ironbaltic.com
www.facebook.com/ironbaltic
www.youtube.com/user/ironbalticLtd

