

IRON BALTIC

ALUMINIUM SKID PLATE

POLARIS

800 Big Boss

Code 02.9600

Version 30102023

DOWNLOAD MULTILINGUAL
USER MANUAL





code.ironbaltic.com/u/YpOxLrH4

Keep this manual for future reference!

If you need any spare parts, please send this packaging data to your local dealer or to Iron Baltic
sales@ironbaltic.com


SPECIFICATION

Pos.	Description	Code	Amount
1	Middle part	02.9601K	1
2	Front part	02.9602	1
3	Rear part 1	02.9603	1
4	Rear part 2	02.9604	1
5	Front right arm protection	02.1402	1
6	Front left arm protection	02.1403	1
7	Rear right arm protection	02.1404	2
8	Rear left arm protection	02.1405	2
9	Middle part bracket 1	02.9608	2
10	Middle part bracket 2	02.9609	2
11	Front part bracket	02.5602	1
12	Installation plate	02.5006	6
13	Installation plate	02.4010	2
14	Installation plate	02.2305	3
15	Installation plate	02.4011	5
16	Clamp for front arm protection	02.1416	1
17	Clamp for front arm protection	02.1417	1
18	Clamp for rear arm protection	02.1418	4
19	Bolt M6x16 DIN 7991	OT.02.04.020	10
20	Bolt M6x20 DIN 7991	OT.02.04.030	24
21	Bolt M6x20 DIN 933	OT.02.02.060	4
22	Bolt M6x35 DIN 7991	OT.02.04.060	2
23	Bolt M8x25 DIN 7991	OT.02.04.160	10
24	Screw 3/16 UNC X 1" x 16	DIN 912	8
25	Conical washer Ø6	14.502	36
26	Conical washer Ø8	14.501	10
27	Washer Ø5/15 DIN 9021	OT.04.02.010	8
28	Washer Ø6/18 DIN 9021	OT.04.02.020	4



FITTING INSTRUCTIONS

Step 1 Remove all standard plastic covers.



Step 2 Install brackets 02.9608, 02.9609 and 02.5602, use bolts M6x20 and washers 6/18.




Step 3

Install middle part 02.9601K, use bolts M6x20.




Step 4

Install plates 02.5006, use bolts M6x16.




Step 5

Install front part 029602, use bolts M6x16 ja M8x25.




Step 6

Install rear part 02.9603, use bolts M6x16, M6x35, M8x25, installation plate 02.5006 and 02.4011.




Step 7

Install rear part 02.9604, use bolts M6x20, M8x25, installation plates 02.4010 and 02.2305.




Step 8

Install front arms protections 02.1402, 02.1403, use bolts M6x20 and front arm clamps 02.1416, 02.1417.



Step 9

Install rear arms protections 02.1404, 02.1405, use bolts M6x20, M8x25, rear arm clamps 02.1418 and installation plate 02.4011.



IRON BALTIC

IRON BALTIC OÜ
Joa tee 17
Vääna 76903
Estonia / Europe

+372 6 533 711
sales@ironbaltic.com

www.ironbaltic.com
www.facebook.com/ironbaltic
www.youtube.com/user/ironbalticLtd

