




LANDSCAPE RAKE

DOWNLOAD MULTILINGUAL
USER MANUAL




code.ironbaltic.com/u/QZvY7hrH

Receiver mount system

Code 84.5000

Version 12082026




Keep this manual for future reference!

If you need any spare parts, please send this packaging data to your local dealer or to Iron Baltic
sales@ironbaltic.com

Iron Baltic Ltd | +372 653 3711 | sales@ironbaltic.com | www.ironbaltic.com

SPECIFICATION



Pos.	Description	Code	Amount
1	Rake holder	84.5001	2
2	Distance plate	84.5002	4
3	U-bolt 50 mm	84.2010	6
4	Rake tine	OT.52.04.010	20
5	Bolt M10x30 DIN933	OT.02.02.320	20
6	Washer Ø10 DIN125	OT.04.01.040	52
7	Nyloc nut M10 DIN985	OT.03.02.050	32



FITTING INSTRUCTIONS

Step 1

Install the rake tines (Pos.4) to the rake holder (Pos.1). For fastening use M10x30 bolts (Pos.5), Ø10 washers (Pos.6) and M10 nyloc nuts (Pos.7).





Step 2

Repeat step 1 to assemble the other side rake set

Step 3

Install the land rake sets to the receiver mount system. For fastening use U-bolts (Pos.3), M10 washers (Pos.6) and Ø10 nyloc nuts (Pos.7). Install distance plates (Pos.2) between two U-bolts and tool holder tube. For easier installation, attach the U-bolts gently to the rake sets and slide on to the tool holder.



IRON BALTIC

IRON BALTIC OÜ
Joa tee 17
Vääna 76903
Estonia / Europe

+372 6 533 711
sales@ironbaltic.com

www.ironbaltic.com
www.facebook.com/ironbaltic
www.youtube.com/user/ironbalticLtd

