

# IRON BALTIC


## ALUMINIUM SKID PLATE

### CAN AM

### Outlander 6x6 (...-2016)

Code 02.20300

Version 15092023



**Keep this manual for future reference!**

If you need any spare parts, please send this packaging data to your local dealer or to Iron Baltic  
[sales@ironbaltic.com](mailto:sales@ironbaltic.com)

Iron Baltic Ltd | +372 653 3711 | [sales@ironbaltic.com](mailto:sales@ironbaltic.com) | [www.ironbaltic.com](http://www.ironbaltic.com)



DOWNLOAD MULTILINGUAL  
USER MANUAL



[code.ironbaltic.com/u/Ap1h3Qe0](http://code.ironbaltic.com/u/Ap1h3Qe0)


# SPECIFICATION

Pos.	Description	Code	Amount
1	Rear part 1	02.20301K	1
2	Rear part 2	02.20302K	1
3	Middle part	02.8401K	1
4	Front part	02.8402K	1
5	Front right arm protection	02.8204	1
6	Front left arm protection	02.8205	1
7	Rear right arm protection	02.8206	2
8	Rear left arm protection	02.8207	2
9	Rear part bracket	02.20303	1
10	Plate for front part	02.10004	1
11	Bush for front part	02.10005	2
12	Clamp for front arm protection	02.8210	4
13	Clamp for rear arm protection	02.5709	4
14	Plate	02.5006	6
15	Plate	02.2305	3
16	Bracket	03.3502	4
17	Dished washer	14.503	43
18	Bolt M6x12 DIN 933	OT.02.02.030	12
19	Bolt M6x16 DIN 933	OT.02.02.050	14
20	Bolt M6x25 DIN 933	OT.02.02.070	4
21	Bolt M6x35 DIN 933	OT.02.02.090	2
22	Bolt M6x50 DIN 933	OT.02.02.120	4
23	Bolt M8x16 DIN 933	OT.02.02.170	6
24	Bolt M8x35 DIN 933	OT.02.02.210	1
25	Bolt M6x25 DIN 7991	OT.02.04.040	3
26	Bolt M8x50 DIN 7991	OT.02.04.200	2
27	Carriage bolt M8x25 DIN 603	OT.02.05.060	8
28	Washer Ø6/15 SFS 3738	OT.04.03.020	53
29	Washer Ø8/20 SFS 3738	OT.04.03.030	10
30	Conical washer Ø6	14.502	3
31	Conical washer Ø8	14.501	2
32	Nyloc nut M6 DIN 985	OT.03.02.030	17
33	Nyloc nut M8 DIN 985	OT.03.02.040	10






# FITTING INSTRUCTIONS


**Step 1** Remove all standard plastic covers.




**Step 2** Install brackets 03.3502. Place brackets same plane as frame.




**Step 3** Install middle part 02. 8401K.





**Step 4** Install plates 02.5006.




**Step 5** Install front part 02.8402K.







**Step 6** Install rear part 02.20301K and plates 02.5006. For easier installation, we recommend removing one wheel.



**Step 7** Install second rear protection 02.20302K.









# IRON BALTIC

IRON BALTIC OÜ  
Joa tee 17  
Vääna 76903  
Estonia / Europe

+372 6 533 711  
[sales@ironbaltic.com](mailto:sales@ironbaltic.com)

[www.ironbaltic.com](http://www.ironbaltic.com)  
[www.facebook.com/ironbaltic](https://www.facebook.com/ironbaltic)  
[www.youtube.com/user/ironbalticLtd](https://www.youtube.com/user/ironbalticLtd)

