




code.ironbaltic.com/u/DTOvsDqZ

ALUMINIUM SKID PLATE

CAN AM Renegade

Code 02.6900

Version 27102023





Keep this manual for future reference!

If you need any spare parts, please send this packaging data to your local dealer or to Iron Baltic
sales@ironbaltic.com

SPECIFICATION

Pos.	Description	Code	Amount
1	Skid plate	02.6901	1
2	Front protection	02.6903K	1
3	Rear protection	02.6902K	1
4	Front right arm protection	02.1512P	1
5	Front left arm protection	02.1512V	1
6	Rear left arm protection	02.1503V	1
7	Rear right arm protection	02.1503P	1
8	Plate	02.5006	4
9	Angle bracket	03.1502	8
10	Angle bracket	02.813	6
11	Bolt M5x25 DIN 933	OT.02.02.010	2
12	Bolt M8x20 DIN 933	OT.02.02.180	2
13	Bolt M6x16 DIN 7991	OT.02.04.020	8
14	Bolt M6x20 DIN 7991	OT.02.04.030	2
15	Bolt M6x25 DIN 7991	OT.02.04.040	10
16	Bolt M8x20 DIN 7991	OT.02.04.150	8
17	Washer Ø5/15 DIN 9021	OT.04.02.010	4
18	Washer Ø6/18 DIN 9021	OT.04.02.020	6
19	Washer Ø8/20 SFS 3738	OT.04.03.030	4
20	Conical washer Ø6	14.502	20
21	Conical washer Ø8	14.501	8
22	Nut M5 Nyloc DIN 985	OT.03.02.020	2
23	Nut M6 Nyloc DIN 985	OT.03.02.030	6
24	Nut M8 Nyloc DIN 985	OT.03.02.040	2




FITTING INSTRUCTIONS

Step 1 Remove all standard plastic covers.




Step 2 Install angle brackets 03.1502 (8 pcs), use original frame bolts, bolts M8x20, washers \varnothing 8/20 and nuts M8.




Step 3

Install skid plate, use bolts M8x20.




Step 4

Install plates 02.5006, use bolts M6x16.




Step 5

Install rear protection, use bolts M6x16 and M8x20.




Step 6

Install front protection, use bolts M6x16, M6x20 and M8x20, washers $\varnothing 6/15$ and nuts M6



Step 7

Install rear A-arms protections, use bolts M6x25, washers \square 6/18 and nuts M6.



Step 8

Install front A-arms protections, use brackets 02.813, bolts M6x25, M5x25, washers \varnothing 5/15 and nuts M5.



IRON BALTIC

IRON BALTIC OÜ
Joa tee 17
Vääna 76903
Estonia / Europe

+372 6 533 711
sales@ironbaltic.com

www.ironbaltic.com
www.facebook.com/ironbaltic
www.youtube.com/user/ironbalticLtd

