

# IRON BALTIC

## MID-MOUNT ADAPTER

### TGB

### Blade 1000

Code 03.8200

Version 09112023



**Keep this manual for future reference!**

If you need any spare parts, please send this packaging data to your local dealer or to Iron Baltic [sales@ironbaltic.com](mailto:sales@ironbaltic.com)

Iron Baltic Ltd | +372 653 3711 | [sales@ironbaltic.com](mailto:sales@ironbaltic.com) | [www.ironbaltic.com](http://www.ironbaltic.com)


DOWNLOAD MULTILINGUAL  
USER MANUAL



[code.ironbaltic.com/u/wX18AxFf](http://code.ironbaltic.com/u/wX18AxFf)

# SPECIFICATION


Pos.	Description	Code	Amount
1	Plow adapter	03.8201K	1
2	Fairlead relocater	03.8202	1
3	Pin 10x40 mm DIN 1444	14.003	2
4	Locker pin 2 mm DIN 11024	OT.07.01.010	2
5	Pipe clamp 38mm	OT.05.01.030	4
6	Bolt M8x20 DIN 933	OT.02.02.180	2
7	Bolt M12x1,25-25 DIN 961	OT.02.08.400	2
8	Washer 8/20 SFS 3738	OT.04.03.030	12
9	Washer M12/24 DIN 125	OT.04.01.050	2
10	Nut M8 Nyloc DIN 985	OT.03.02.040	10



# FITTING INSTRUCTIONS


## Step 1

Install plow adapter. If fitted with original plastic protection, drill holes for U-bolts.



## Step 2

Install fairlead relocator if your ATV is „tractor“ modification.



# IRON BALTIC

IRON BALTIC OÜ  
Joa tee 17  
Vääna 76903  
Estonia / Europe

+372 6 533 711  
[sales@ironbaltic.com](mailto:sales@ironbaltic.com)

[www.ironbaltic.com](http://www.ironbaltic.com)  
[www.facebook.com/ironbaltic](https://www.facebook.com/ironbaltic)  
[www.youtube.com/user/ironbalticLtd](https://www.youtube.com/user/ironbalticLtd)

