

IRON BALTIC

CHAINSAW HOLDER


DOWNLOAD MULTILINGUAL
USER MANUAL



code.ironbaltic.com/u/oBSHAcl7

Code 14.7000

Version 01122023




Keep this manual for future reference!

If you need any spare parts, please send this packaging data to your local dealer or to Iron Baltic
sales@ironbaltic.com

Iron Baltic Ltd | +372 653 3711 | sales@ironbaltic.com | www.ironbaltic.com

SPECIFICATION

Pos.	Description	Code	Amount
1	Holder	14.7100	1
2	Bracket 1	14.7003	1
3	Bracket 2	14.7004	1
4	U-clamp M8x28	OT.05.01.010	2
5	Bolt M6x45 DIN7991	OT.02.04.075	4
6	Bolt M8x20 DIN933	OT.02.02.180	4
7	Washer 6/15 SFS3738	OT.04.03.020	4
8	Washer 8/20 SFS3738	OT.04.03.030	12
9	Nyloc nut M6 DIN985	OT.03.02.030	4
10	Nyloc nut M8 DIN985	OT.03.02.040	8



SAFETY INSTRUCTIONS


- Do not place the saw with the engine running in the saw holder!
- Note that when installing the saw holder the overall dimensions of the vehicle change, making it difficult to drive in narrow areas!
- Install the saw holder so that it does not touch the ATV's wheels, handle bar, or other parts of the vehicle that could prevent the ATV from being handled safely.



USER GUIDE

Step 1 Install saw holder to ATV luggage rack. Use U-clamps.

Step 2 The saw holder can be positioned in different positions. To adjust the position, loosen the bolts as shown in the drawing, select the suitable position for the saw holder and retighten the bolts.



IRON BALTIC

IRON BALTIC OÜ
Joa tee 17
Vääna 76903
Estonia / Europe

+372 6 533 711
sales@ironbaltic.com

www.ironbaltic.com
www.facebook.com/ironbaltic
www.youtube.com/user/ironbalticLtd

