

PLOW BLADE EXTENSIONS

DOWNLOAD MULTILINGUAL
USER MANUAL



code.ironbaltic.com/u/8LP6OtJ

2-in-1 Modular plow bucket

Code 20.7660

Version 04122023





Keep this manual for future reference!

If you need any spare parts, please send this packaging data to your local dealer or to Iron Baltic
sales@ironbaltic.com


SPECIFICATION

Pos.	Description	Code	Amount
1	Left extension	20.7661S	1
2	Right extension	20.7662S	1




FITTING INSTRUCTIONS



Step 1 Install extensions into the slot in the plow.



Step 2 Secure the extension with the locking pin.



Step 3 Tighten the extension to plow blade with an eccentric clamp.
NB! When installing the extensions for the first time, it is necessary to adjust the length of the eccentric clamp so that you can push the eccentric lever to the locked position without much force.



IRON BALTIC

IRON BALTIC OÜ
Joa tee 17
Vääna 76903
Estonia / Europe

+372 6 533 711
sales@ironbaltic.com

www.ironbaltic.com
www.facebook.com/ironbaltic
www.youtube.com/user/ironbalticLtd

