

# IRON BALTIC

## PVC COVER

## SAND SPREADER

### G2 500 Pro

Code 52.5100

Version 18122023



DOWNLOAD MULTILINGUAL  
USER MANUAL



[code.ironbaltic.com/u/jW02noPu](https://code.ironbaltic.com/u/jW02noPu)

**Keep this manual for future reference!**

If you need any spare parts, please send this packaging data to your local dealer or to Iron Baltic  
[sales@ironbaltic.com](mailto:sales@ironbaltic.com)

Iron Baltic Ltd | +372 653 3711 | [sales@ironbaltic.com](mailto:sales@ironbaltic.com) | [www.ironbaltic.com](http://www.ironbaltic.com)

# SPECIFICATION

Pos.	Description	Code	Amount
1	PVC Cover	52.5101	1
2	Support arm	52.5105	4
3	Cord eyelet	OT.10.15.010	2
4	Rivet 6x18	OT.06.01.042	2
5	Self-tapping screw 4,8x25mm	OT.01.02.055	2


# FITTING INSTRUCTIONS

## Step 1

Install support arms (Pos. 2) and if desired then cord eyelets (Pos. 3).

There is two options to install cord eyelets:

- 1) Riveting - for riveting cord eyelets drill  $\varnothing 6$  mm holes on the front and back of the spreader (185 mm from the top edge).
- 2) Self-tapping screw – use electric/cordless drill with suitable socket to install the eyelet on the front and back of the spreader (185mm from the top edge).



## Step 2

Install PVC cover (Pos. 1).



# IRON BALTIC

IRON BALTIC OÜ  
Joa tee 17  
Vääna 76903  
Estonia / Europe

+372 6 533 711  
[sales@ironbaltic.com](mailto:sales@ironbaltic.com)

[www.ironbaltic.com](http://www.ironbaltic.com)  
[www.facebook.com/ironbaltic](https://www.facebook.com/ironbaltic)  
[www.youtube.com/user/ironbalticLtd](https://www.youtube.com/user/ironbalticLtd)

