

IRON BALTIC

LIFT CYLINDER ADAPTER

ARCTIC CAT

Alterra XT 700 (2017-...)

Code 71.9000

Version 03012024



Keep this manual for future reference!

If you need any spare parts, please send this packaging data to your local dealer or to Iron Baltic
sales@ironbaltic.com

Iron Baltic Ltd | +372 653 3711 | sales@ironbaltic.com | www.ironbaltic.com


DOWNLOAD MULTILINGUAL
USER MANUAL



code.ironbaltic.com/u/ITJogTTp

SPECIFICATION



Pos.	Description	Code	Amount
1	Bracket	71.9001	1
2	Cylinder holder	71.9002K	1
3	Lower cylinder bracket	71.3003	1
4	Pin	71.3004	1
5	Pin	71.3005	1
6	Bush	71.3006	2
7	Pipe clamp bracket 28	OT.05.04.010	2
8	Cotter pin 3	OT.07.01.020	2
9	Bolt M8x25 DIN 933	OT.02.02.190	4
10	Bolt M8x45 DIN 933	OT.02.02.230	4
11	Bolt M12x30 DIN 933	OT.02.02.390	1
12	Washer ø8/20 SFS 3738	OT.04.03.030	16
13	Washer 12/24 DIN125	OT.04.01.050	1
14	Nut M8 Nyloc DIN 985	OT.03.02.040	8
15	Nut M12 Nyloc DIN 985	OT.03.02.060	1



FITTING INSTRUCTIONS

Step 1

Remove winch cover / hook and fairlead. Install cylinder holder to the bracket.




Step 2

Install bracket and fairlead. Install bracket between skid plate and frame.




Step 3

Install frame bracket.




Samm 4

Install bracket.



Step 5

Install cylinder. Find appropriate height for cylinder, if cylinder is in minimal position then plow frame should not touch ATV.



IRON BALTIC

IRON BALTIC OÜ
Joa tee 17
Vääna 76903
Estonia / Europe

+372 6 533 711
sales@ironbaltic.com

www.ironbaltic.com
www.facebook.com/ironbaltic
www.youtube.com/user/ironbalticLtd

