

IRON BALTIC

GAS SPRING

TRAILER

IB-165

Code 74.4000

Version 05012024



Keep this manual for future reference!

DOWNLOAD MULTILINGUAL
USER MANUAL




code.ironbaltic.com/u/MgFIIJxk

If you need any spare parts, please send this packaging data to your local dealer or to Iron Baltic
sales@ironbaltic.com

Iron Baltic Ltd | +372 653 3711 | sales@ironbaltic.com | www.ironbaltic.com

SPECIFICATION


Pos.	Description	Code	Amount
1	Bottom attachment	70.8001K	1
2	Bush longer	74.4001	2
3	Bush shorter	74.4002	2
4	Gas spring 600x350N	OT.35.00.050	1
5	U-Bolt	23.1006	2
6	Bolt M8x60 DIN931	OT.02.01.015	1
7	Bolt M8x65 DIN931	OT.02.01.013	1
8	Washer 8/20 SFS3738	OT.04.03.030	4
9	Washer 10/20 DIN 125	OT.04.01.040	4
10	Nut M8 Nyloc DIN 985	OT.03.02.040	2
11	Nut M10 Nyloc DIN 985	OT.03.02.050	4



FITTING INSTRUCTIONS



Step 1

Install bottom cylinder attachment to the tow beam.



Step 2

Install gas spring.



IRON BALTIC

IRON BALTIC OÜ
Joa tee 17
Vääna 76903
Estonia / Europe

+372 6 533 711
sales@ironbaltic.com

www.ironbaltic.com
www.facebook.com/ironbaltic
www.youtube.com/user/ironbalticLtd

