



DOWNLOAD MULTILINGUAL
USER MANUAL



code.ironbaltic.com/u/ofyBSFRW

SUPPORT WHEEL

For receiver mount system

Code 84.21000

Version 06042025




Keep this manual for future reference!

If you need any spare parts, please send this packaging data to your local dealer or to Iron Baltic
sales@ironbaltic.com

SPECIFICATION


Pos.	Description	Code	Amount
1	Support wheel mounting adapter	84.21001K	1
2	Support wheel mounting tube	84.21004K	1
3	U-bolt 50 mm	84.2010	2
4	Wheel 4,80/4,00-8"	OT.26.00.020	1
5	Quick-Lock pin	OT.53.00.045	1
6	Bolt M10x80 DIN933	OT.02.02.355	1
7	Washer Ø 10 DIN125	OT.04.01.040	6
8	Washer Ø 16 DIN125	OT.04.01.060	1
9	Nyloc nut M10 DIN985	OT.03.02.050	5
10	Nyloc nut M16 DIN985	OT.03.02.070	1



FITTING INSTRUCTIONS


Step 1

Install support wheel adapter (Pos.1) to mounting tube (Pos.2). For fastening use M10x80 bolt (Pos.6), Ø10 mm washers (Pos.7) and M10 nyloc nuts (Pos.9). Fix the position of the mounting tube with the quick-lock pin (Pos.5).




Step 2

Install the wheel (Pos.4). For fastening use Ø16 mm washer (Pos.8) and M16 nyloc nut (Pos.10).




Samm 3

Install completed support wheel to the receiver mount system. For fastening use U-bolts (Pos.3), Ø10 mm washers (Pos.7) and M10 nyloc nuts (Pos.9).




USER MANUAL


If you use the support wheel with the plough (84.22000), install the support wheel so that it is located behind the plough and rolls on the unploughed ground.




If you are using the support wheel with the ridge plough (84.23000), install the support wheel so that it is located in front of the plough and rolls in line with the plough blade.



If you use the support wheel with the potato harvester (84.24000), install the support wheel so that it rolls in the furrow gap.



To adjust the height of the support wheel and the depth of the plough, remove the quick-lock pin, select the position and fix the position again with the pin.



IRON BALTIC

IRON BALTIC OÜ
Joa tee 17
Vääna 76903
Estonia / Europe

+372 6 533 711
sales@ironbaltic.com

www.ironbaltic.com
www.facebook.com/ironbaltic
www.youtube.com/user/ironbalticLtd

