DOWNLOAD MULTILINGUAL USER MANUAL

code.ironbaltic.com/u/UPeBFvZ3

LIFT CYLINDER MOUNT

SUZUKI

LT-A 450 / 700 / 750 KingQuad

Code 71.10100

Version 04012024

Keep this manual for future reference!

If you need any spare parts, please send this packaging data to your local dealer or to Iron Baltic sales@ironbaltic.com

Iron Baltic Ltd | +372 653 3711 | sales@ironbaltic.com | www.ironbaltic.com

SPECIFICATION

Pos.	Description	Code	Amount
1	Rack bracket support	71.10101	1
2	Bracket	71.3001	1
3	Rack bracket	71.3002	1
4	Lower cylinder bracket	71.3003	1
5	Pin	71.3004	1
6	Pin	71.3005	1
7	Bush	71.3006	2
8	Cylinder holder	71.3010	1
9	Bracket	02.4606	2
10	Cotter pin 3	OT.07.01.020	2
11	Bolt M6x16 DIN 933	OT.02.02.050	4
12	Bolt M8x16 DIN 933	OT.02.02.170	3
13	Bolt M8x25 DIN 933	OT.02.02.190	8
14	Bolt M10x25 DIN 933	OT.02.02.317	2
15	Bolt M12x30 DIN 933	OT.02.02.390	1
16	Washer 6/15 SFS3738	OT.04.03.020	4
17	Washer 8/20 SFS3738	OT.04.03.030	19
18	Washer 12/24 DIN 125	OT.04.01.050	1
19	Nut M8 Nyloc DIN 985	OT.03.02.040	8
20	Nut M12 Nyloc DIN 985	OT.03.02.060	1


11
3
17
16
9
12
9
1
19
17
19
17
10
14
2
19
17
15
7
5
17
13
8
10
6
4
17
13
20
18

FITTING INSTRUCTIONS

Step 1 Remove winch hook and fairlead. Install bracket and fairlead.





Step 2 Install rack bracket support and rack bracket.



Step 3

Install rack bracket support and rack bracket.





Step 4

Install cylinder holder to plow pushtubes.



Step 5

Install cylinder. Find appropriate height for cylinder, if cylinder is in minimal position then plow frame should not touch ATV.

IRON BALTIC OÜ
Joa tee 17
Vääna 76903
Estonia / Europe

+372 6 533 711
sales@ironbaltic.com

www.ironbaltic.com
www.facebook.com/ironbaltic
www.youtube.com/user/ironbalticltd